



FITTING GUIDE

Piranha Off Road Products are not associated in any way with Toyota Australia or any of its related companies

DETAILS	
Part Number	BTPRAD
Approx. Fitting Time	.5 Hour
Max Battery Size	300mm Long
Max Battery Weight	23Kg
Battery Type	Cycle Duty
Tray Location	PSF

To Suit Prado 90 Series 1KZ-TE 3.0L TDI

Recommended Isolator
DBE140SF or DBE180-SX

PARTS INCLUDED WITH TRAY			
1	Tray	6	1 x Body Washer
2	2 x M6 Bolts	7	1 x M8 Bolt Short
3	1 x M6 Nut	8	Special Top Mount
4	1 x M6 Washer	9	2 x J Bolts
5	1 x M8 Nut		



FITTING INSTRUCTIONS

1. Remove air intake pipe that runs along and into the guard.
Note – You may need to remove inner guard to refit pipe after the tray is in.
2. Place tray in position and make sure arm is under the air cleaner support, use existing bolt.
3. Screw M6 bolt into existing captive nut in guard.
4. Drill 6mm hole under leg at the front of the tray, and fit M6 nut, bolt & washer.
5. Tighten all nuts and bolts.
6. Install battery and fit Top Mount, use M8 bolt & nut to secure radiator support panel.



Please Note: It is the installers responsibility to check all items have adequate clearance and are secured/protected against vibration, rubbing & chaffing.